

SPERLING - SIZE 60 FITTING INSTRUCTIONS

SEAT COVERS USING THIS COMPUTER CONTROLLED STITCHING PROCESS HAVE BEEN TESTED BY APV-T AND FOUND TO NOT OBSTRUCT THE DEPLOYMENT AND POSITION OF THE AIR BAG.
FOR FULL DETAILS OF THE TEST REPORT
REFER TO OUR WEBSITE WWW.SPRLING.COM.AU

CAUTION

THESE SEAT COVERS ARE DESIGNED FOR CARS WITH OR WITHOUT STANDARD SIDE AIRBAGS. PLEASE READ AIRBAG DISCLAIMER BELOW. UNDER NO CIRCUMSTANCES SHOULD THE SIDE OF THE SEAT COVER BE OBSCURED.


AIRBAG DISCLAIMER

THIS PRODUCT IS SUITABLE FOR CARS WITH STANDARD SIDE AIRBAGS. BEFORE FITTING PLEASE READ BELOW.

1. CORRECT INITIAL FITTING AND SECURING OF THIS SEAT COVER ON YOUR VEHICLE IS ESSENTIAL TO ALLOW DEPLOYMENT OF SEAT AIRBAG. INCORRECT FITTING CAN PREVENT THE SEAT AIRBAG FROM INFLATING CORRECTLY IN THE EVENT OF A COLLISION.
2. THE SEAT COVERS CAN BE FITTED TO EITHER THE DRIVERS SIDE OR PASSENGERS SIDE, AS THERE ARE AIRBAG PROVISIONS ON BOTH SIDES OF THE SEAT COVERS.
3. SEAT COVERS THAT HAVE SLIPPED MUST BE REPOSITIONED. IF THIS IS NO LONGER POSSIBLE BECAUSE OF ADVANCED WEAR THE SEAT COVER MUST BE REPLACED.
4. DO NOT TAMPER WITH THE OPENING SIDE SEAM OF THE SEAT COVER.
5. THESE SEAT COVERS ARE DESIGNED TO ALLOW THE SIDE SEAMS TO SPLIT OPEN UPON DEPLOYMENT OF AN AIRBAG BECAUSE THEY ARE CONSTRUCTED USING A COMPUTER CONTROLLED STITCHING PROCESS AND SPECIALISED THREAD.
6. IF THE SIDE SEAM SPLITS FOR ANY REASON IT CANNOT BE REPAIRED. ANY ATTEMPT TO RESEW THE SEAM MAY INTERFERE WITH THE STANDARD INTEGRATED SIDE AIRBAG DEPLOYMENT.
7. DISCARD THE SEAT COVERS AFTER SIDE AIRBAG ACTIVATION.
8. PLEASE CAREFULLY FOLLOW FITTING INSTRUCTIONS BELOW.

FITTING INSTRUCTIONS

HOW TO FIT SIDE AIRBAG COMPATIBLE SEAT COVERS




1. Pull cover forward over seat base. Ensure cover is centralised from side to side. Feed triangle ties (with D-rings) between the backrest and seat base.



2. Fit backrest section of seat cover over seat back working the backrest section down the seat, ensure pattern on cover is central and balanced side to side.



3. Feed the two long ties at the front of the cover under the seat towards the back. Then from behind the seat, loop through rings attached to the triangle centre ties by firmly pressing together



4. Pull side ties down. Pass the long tie under the seat (or) behind the seat floor mountings and simply attach by pressing together.

5. From behind seat, pull down the two ties on bottom of the polyester backing (of the seat cover). Pull under seat & press onto the two triangle ties (as shown in fig 3).